



DID-6P3

Maintenance Manual





YANGSAN MACHINERY



DID-6P3_Disassembly



1)제품 확인




2)SNAP RING 분해




3)BIT SLEEVE 분해 모습



4)BOLT 분해



5)HAMMER CASING 분해



6)HAMMER CAGE 분해



DID-6P3_Disassembly



7)PACKING 분해




8)SPACER 분해




9)HAMMER CASING JOINT 분해



10)O-RING 분해



11R)ROTOR ASSY 분해




12)HAMMER,ROTOR ASSY
분해 모습



DID-6P3_Disassembly



13)FRONT PLATE 분해




14)CYLINDER 분해




15)BLADE 분해



16)REAR PLATE BEARING 분해



17)HAMMER PIN 분해



18)HAMMER 분해



DID-6P3_Disassembly



19)CAM HAMMER 분해




20)전체 분해 모습




21)ROTOR와 REAR PLATE 조립



22)BLADE 조립



23)CYLINDER 조립




24)FRONT PLATE 조립




DID-6P3_Disassembly



25)CASING에 ROTOR ASSY 조립




26)O-RING 조립




27)JOINT 조립



28)CAM HAMMER 조립



29)HAMMER 조립




30)CAM HAMMER 조립



DID-6P3_Disassembly



31)HAMMER 조립




32)HAMMER PIN 조립




33) DRIVER ANVIL,
HAMMER CAGE BUSHING 조립



34) SPACER 조립



35)HAMMER CAGE ASSY 조립




36)HAMMER CASING 조립



DID-6P3_Disassembly



37)BOLT 조립



38)TEST